



RENAULT TRAFIC 01- (828190)

- * Paigaldada kinnitused nr. 2, 4 ja 5.
- * Lõigata ava läbi plastiku.
- * Paigaldada küljeraud.

- * Mount brackets 2, 4 and 5.
- * Cut the opening trough the plastic shield.
- * Mount the side bar.

	Arv, tk./Pcs.
1 - Küljeraud (side bar)	1+1
2 - Kronstein (bracket)	2
3 - U-polt (u-bolt)	2
4 - Plaat (bracket)	2
5 - Plaat (bracket)	2
6 - Polt (bolt) M10x25 mm	20
7 - Mutter (nut) M10 DIN 934	4
8 - Mutter (nut) M10 DIN 985	20
9 - Seib (washer) 10.5x30x2.5 mm	44
10 - Vedruseib (spring washer) A10	4